


Fuel Injection Components



Fuel filter	Injector pump
Fuel return pipe	Manual primer/pump
High pressure delivery pipe	Low pressure fuel pick up pipe
injector	Air bleeder screw

Print laminate and cut out components to match where they go on the diagram.