



STEERING LINKAGES

Spindle turns the stub axle

Tie Rod End a ball joint that swivels to move the spindle

Drag Link connects the tie rods, tie rod arms, stub axle and wheels in parallel

Idler Arm connects the drag link to the fixed idler arm support

Recirculating Ball provides reduction gearbox and transfers rotation of steering column to Pitman arm

Tie Rod Arm Sleeve allows for toe-in and toe-out adjustments